NOTICE:
For the need of technical improvement and system upgrade, information contained herein may be subject to change from time to time without prior notice

Copyright ©2010
All Rights Reserved.
Manual Edition 1.5, Mar. 2010
Printed in China

Edifier
www.edifier.com
Edifier International Limited
Made in China

Products of Edifier will be customized for different applications. Pictures and illustrations shown on this manual may be slightly different from actual product. If any difference is found, the actual product prevails.

Edifier



English
Français
Español
Deutsch
Italiano

HCS5640 Multimedia Speaker

User's Manual
Please carefully read this manual before operating the system

Important safety instruction

Thank you for purchasing this Edifier product. For generations, Edifier tries to provide powered speaker products to satisfy the need of our end customers, even the most demanding ones. This product can add to your home entertainment, personal computer, and mini home theater great sound performance. Please read this manual carefully to obtain the best of this system.

CAUTION
RISK OF ELECTRIC SHOCK DO NOT OPEN

The lightning flash with arrowhead inside the triangle, is intended to alert the user to the presence of un-insulated dangerous voltage within the product's enclosure that may be of a sufficient magnitude to constitute a risk of electric shock to persons.

To prevent the risk of electric shock, do not remove cover (or back). No user-serviceable Parts inside. Refer servicing to qualified Service personnel only.

The exclamation point inside the triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

SAFETY INSTRUCTIONS

Please read all the instructions herein. Please retain this manual safely for future reference.
Please heed all safety warnings. Please install in accordance with the manufacturer's instructions.
Please adjust the volume control to a comfortable level to avoid damaging your hearing and the system.

- Do not expose this apparatus to rain or moisture.
- Do not use the speakers near water, and do not immerse them in any liquid or pour any liquid on them.
- Do not defeat the safety purpose of the polarized plug. A polarized plug has two blades with one wider than the other.
- For added protection during lightning storms, unplug the speakers from the electrical outlet and turn off the computer.
- Unplug this apparatus when unused for long periods of time.
- Place the speakers away from all heat sources, such as heaters, stoves, and direct sunlight.
- Do not block the openings in the speaker cabinets. Never push objects into speaker vents or slots. Prevent risk of fire or electric shock hazards, and provide sufficient space around the speakers for proper ventilation.
- Place the speakers in a stable location so that it will not fall causing damage to the speakers or bodily harm.
- Unplug the speakers from the computer and from the electrical outlet before cleaning them with a damp cloth.
- Servicing is required when the apparatus has been damaged in any way, such as the power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped. Refer all servicing to qualified service personnel only.
- Use the plug or the coupler inlet to disconnect with mains.

Unpack the box

Box content

- Amplifier x 1
- Subwoofer x 1
- Satellite speaker x 5
- Remote control (RC60) x 1
- 40-strand satellite connecting cable x 6
- 3.5mm to dual RCA connecting cable x 1
- 2P-2P RCA connector cable x 3
- Power cable x 1
- Radio antenna x 1
- Battery x 2
- User's manual x 1

Satellite connecting cable, Radio antenna, Power cable, 3.5mm to dual RCA connecting cable, RCA connector cable, User's manual, Remote control, Subwoofer, Amplifier, Satellite speaker

Illustrations and Functional Depict

1. Display panel

2. " << ":

USB/SD	To skip to the previous track in the selected folder
FM	To seek into lower frequency until locking down one channel
PC/AUX/5.1	Do nothing

3. " ■ ":

USB/SD	To stop playing
FM	Do nothing
PC/AUX/5.1	Do nothing

4. " ►II ":

USB/SD	To start playing/pause
FM	Do nothing
PC/AUX/5.1	Do nothing

5. " >> ":

USB/SD	To skip to the next track in the selected folder
FM	To seek into higher frequency until locking down one channel
PC/AUX/5.1	Do nothing

6. " FUNCTION ":

USB/SD / FM / PC/AUX/5.1	To navigate among SUB/Front/CE/Rear/Bass/Treble/LCD light/SUR adjustment interface, it works together with the "ADJ" key

7. " VOLUME/ADJ " knob

USB/SD / FM / PC/AUX/5.1	Rotate to complete master volume, bass, treble and other trimmer adjustment

Front view of amplifier

Illustrations and Functional Depict

8. Power indicator halo

9. " INPUT ":

USB/SD / FM / PC/AUX/5.1	To switch among different input selections: SD->USB->AUX->PC->5.1->FM

10. " MUTE ":

USB/SD / FM / PC/AUX/5.1	MUTE

11. " 🎧 ":
In any mode, inserting the 3.5mm headphone plug darkens the orange halo around the VOLUM/ADJ knob, and the display panel will show the word "PHONE", indicating that the sound would solely output from the headphone.

12. "AUX" : Front mounted AUX input port
13. IR receiver
14. USB input
15. SD input
16. Radio antenna connecting port
17. PC input port
18. 5.1 input port
19. Output for satellite
20. Fuse
21. Power cord
22. Power switch

Rear view of amplifier

Making connection

Radio antenna, SD input, USB input, 5.1 input: FR— Front right, FL — Front left, SR — Surround right, SL — Surround left, SW — Subwoofer, CE — Center; Front left, Front right, Surround left, Surround right, Center, Subwoofer, To AC power

Illustrations and functional depict of remote controller

Guidance for using remote controller

1. Mute
2. " ESC " : Press this key to go back to the main interface.
3. Keys for FM mode
 a."REGION": press this key repeatedly to select among 4 broadcasting regions: CN-US-AU-JP
 b."AUTO": press to seek automatically until locking down one channel
 c."1-6": 1) press and hold anyone of them to store the current channel as a preset radio station, with the chosen figure settled as the preset index number; 2).
 Press to skip to a stored radio station.
4. Keys for USB/SD mode
 a."REPEAT": 1).Press this key repeatedly to select among 3 ways of track repeating: ALL TRACK, FOLDER, ONE TRACK; 2) When shuffle function is turned on, press this key to turn it off.
 b."SHUFFLE": Press this key, and the word "SHUFFLE" will be shown on the display panel, indicating the shuffle function is activated. Then you could press ">>" or "<<" key to play from songs of different folders at random, or press "REPEAT" to turn this function off.
5. Input selection keys: Press one of these keys to choose the corresponding input mode.
6. " ADJ+/- " : Works together with "FUNC" key to achieve trimmer and LCD light level adjustment.
7. " LIGHT+/- " : Press +/- to bring up / down light level of the LCD screen.

Illustrations and functional depict of remote controller

8. Navigation keys:

Button	Message	Mode	Response
<	Press	USB/SD	To move to the previous folder, and start playing from the 1st song of that folder
	Press	FM	To tune to lower frequency by one step (0.1MHz)
	Press and hold		To tune to lower frequency continuously with 0.1MHz every step
	Press	PC/AUX/5.1	Do nothing
>	Press	USB/SD	To move to the next folder, and start playing from the 1st song of that folder
	Press	FM	To tune to higher frequency by one step (0.1MHz)
	Press and hold		To tune to higher frequency continuously with 0.1MHz every step
	Press	PC/AUX/5.1	Do nothing
VOL+/VOL-	Press	USB/SD/FM/	To bring the volume up/down step by step, totally 50-level master volume adjustment
	Press and hold	PC/AUX/5.1	To increase / decrease master volume continuously
«	Press	USB/SD	To move to the previous song of the same folder
		FM	To seek into lower frequency until locking down one channel
		PC/AUX/5.1	Do nothing
»	Press	USB/SD	To move to the next song of the same folder
		FM	To seek into higher frequency until locking down one channel
		PC/AUX/5.1	Do nothing
►II	Press	USB/SD	To play /pause the current track
		FM	Do nothing
		PC/AUX/5.1	

9. " FUNC " : press repeatedly to switch among SUB/Front/CE/Rear/Bass/Treble/LCD light/SUR ON & OFF adjustment interfaces, then press the "ADJ +/-" key or rotate the "VOLUME/ADJ." knob to complete the adjustment.

Illustrations and functional depict of remote controller

Battery loading:
Please refer to the figure on the right side to open the battery compartment, load the battery as the picture shows and shut the compartment.

Note:
- Do not place the remote in places that are hot and moist;
- Unload the battery when unused for long period of time.

Tuning the radio

1. When FM input mode is selected, the LCD display panel would be like the picture below, showing the current FM information:

Input mode, Preset index number, Subwoofer & satellite channel, FM frequency — 3 100.80

2. Press "REGION" key on the remote controller repeatedly until the region in which you live is selected.
3. To find a frequency station with a strong signal, at least one of the following operations should be done in FM mode:
 1). Press ">>" on either the amplifier front panel or the remote controller to automatically find a higher frequency, and "<<" for a lower frequency. When a frequency station is found, long press one of the preset buttons (1~6) on the remote controller for 3 seconds to store it for a quick recall. Totally 6 preset stations could be stored, sequence number is marked respectively as 1~6.
 2). Press ">/ <" on the remote controller to manually tune to a higher/lower frequency. Every single press brings the frequency value up/down by 0.1MHz. When a satisfying frequency station is found, long press the one of the preset buttons for 3 seconds to store it.
 3). Press "AUTO" on the remote controller to seek automatically until one channel is locked down.
4. Navigating through preset stations: press different preset keys to navigate from one preset radio station to another.

Specification

Power output: RMS 5 x 8W + 30W (THD + N=10%)
Signal to noise ratio: ≥85 dB (A)
Distortion: ≤0.5%
Input type: FM/SD/USB/PC/AUX/5.1
Input sensitivity: Satellites: 5.1CH: 250mV ± 50mV (THD + N=1%)
PC: 450mV ± 50mV (THD + N=1%)
AUX: 300mV ± 50mV (THD + N=1%)
Subwoofer: 5.1CH: 150mV ± 50mV (THD + N=1%)
PC: 200mV ± 50mV (THD + N=1%)
AUX: 150mV ± 50mV (THD + N=1%)
Adjustment: Master volume control, bass / treble trimmer on amplifier and remote controller
Bass unit: 8.25 inch (210mm), magnetically shielded, 4Ω
Mid-range unit: 3.5 inch (92mm), magnetically shielded, 4Ω
Treble unit: 2.75 inch (72mm), magnetically shielded, 4Ω
Dimension: Subwoofer: 268 x 330 x 309 mm (W x H x D)
Center satellite: 316 x 117 x 157 mm (W x H x D)
FL/FR/SL/SR satellite: 116 x 203 x 160 mm (W x H x D)
Power amplifier: 95 x 285 x 263 mm (W x H x D)
Gross weigh: Subwoofer: approx 14.3kg; Satellites: approx 10kg
Net weigh: Subwoofer: approx 12.8kg; Satellites: approx 8.3kg

Warnings:
Please do not feed powered signal from another amplifier into the input ports of this system!
Please adjust to a comfortable volume to avoid damaging your hearing and the system!
Dangerous voltage inside the subwoofer enclosure, please do not open the chassis.
Refer to qualified personnel for servicing.
Please remove the power plug if the system is unused for long period of time.
Please do not expose the system in rain or moisture environment.
Please do not place vase or utensil full of liquid on the speaker.

Troubleshooting

■ Not all speakers function:
Please first check if the speaker wires are connected securely; then check if the Line-in connectors are reversed; check also if the audio source is at fault.

■ One satellite speaker does not function when playing CD from computer:
This kind of phenomena is prone to happen on new computer systems that one satellite does not function when playing CD, but system works fine when playing WAV formatted files. This is mainly due to the fault connection of CD-ROM and sound card, that one channel of signal is shorted to the ground. Please refer to the manual of CD-ROM and sound card to adjust the wire connection.

■ System does not work at all:
1. Please check if power is connected, and if the wall outlet is switched on.
2. Please check if the master volume is turned to minimum
3. Please check if the audio input cable is connected correctly
4. Please check if there is signal from audio source

■ Noise coming from speakers:
Amplifier circuitry of this product generates little noise, while the background noise of some VCD/DVD player or computer sound card are too high. Please keep the system in active mode and remove the audio source, if no sound can be heard at 1 meter away from the system, then there is no problem with this product.

■ Magnetic interference:
This system is complete magnetically shielded, and can be placed near TV or monitor. But since magnet of the subwoofer driver is large, some magnetism leakage is inevitable when the system is too close to the monitor, and it is recommended to keep a 1 meter distance between the speaker system and monitor or TV set.

☎ If you have any further questions or concerns regarding Edifier Products:
Please visit our website at: www.edifier.com, or email Edifier Support for further assistance at: main@edifier.com, If you prefer, you may contact us by phone, Toll Free: 1-877-EDIFIER (334-3437).

Consignes de securite importantes

Déballer la boîte

Contenu

- Amplificateur x 1
- Caisson de basse x 1
- Haut-parleur satellite x 5
- Télécommande (RC60) x 1
- Câbles de connexion satellite 40 brins x 6
- Câble de connexion RCA 3.5mm à duel x 1
- Câbles connecteur RCA 2P-2P x 3
- Câble d'alimentation x 1
- Antenne radio x 1
- Batterie x 2
- Guide d'utilisation x 1

Illustrations et description des fonctions

Connexions

Illustrations et description des fonctions de la télécommande

Réglage de la radio

Caractéristiques techniques

Guide de dépannage

Instrucciones importantes de seguridad

Desembalar la caja

Ilustraciones y descripción funcional

Cómo realizar las conexiones

Ilustraciones y descripción funcional del mando a distancia

Sintonizar la radio

Especificaciones

Resolución de problemas

Wichtige Sicherheitshinweise

Auspacken

Abbildungen und Funktionsbeschreibung

Anschlüsse herstellen

Abbildungen und Funktionsbeschreibung der Fernbedienung

Abstimmen des Radios

Spezifikationen

Fehlerbehebung

IMPORTANTI ISTRUZIONI DI SICUREZZA

Apertura della confezione

Illustrazioni e descrizione delle funzioni

Esecuzione dei collegamenti

Illustrazioni e descrizione delle funzioni del comando remoto

Sintonizzazione della radio

Specifiche

Risoluzione dei problemi